



## Parts List (\*Memory not included.)




## Intel Installation Guide

1




2

1700/1200/1156/1155/1151/1150




2066/2011-3/2011




## AMD Installation Guide

1




2




3


Tighten screw 1 again to ensure your waterblock is secure enough.



## Installation Guide (\*Floe RC Ultra AIO is only compatible with TOUGHRAM RC Series.)



## MB SYNC Installation Guide



### ⚠ CAUTION

To control the LCD display by TT RGB PLUS Software, Please connect the water block and motherboard with cable M.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.