

Pure Duo 12 / 14 RGB

ARGB Sync Radiator Fan



Parts List















3 x 1 **ARGB Controller**

© x 8 Long Screw

① x 8 Short Screw


() x 1 Mainboard Signal Bridge Cable (ASUS,MSI)

(a) x 1 Mainboard Signal Bridge Cable (GIGABYTE)


© x 1 **PWM Cable**

Installation Guide






Install the fans properly onto the radiator




Connect the Fans in series













Connect the fan power cable to PWM cable

ARGB Controller Installation Guide



Connect the ARGB controller to the Fans.





Connent the ARGB controller to the SATA connector.

Mianboard SYNC installtation Guide



Please power off the PC and check the Positive and Negative ends on the connector before connecting the cable to mainboard. Connecting the wrong end can damage the fans.

Connect the Mainboard Signal Bridge Cable to fan led cable












Aura Addressable Strip Header(s)




MODE

COLOR

SPEED




JRGB-strip Header(S)



GIGABYTE

AOURS RGB Fusion with Digital LEDs



ARGB Controller

⚠ CAUTION:

Long press mode button for three seconds, then change the lighting to the preferred mode for outside or inside LED Rings after fan blinks three times.

1. Light Mode:

Switch over between 7 LED modes.

 $\mathsf{Wave} \to \mathsf{Full}\, \mathsf{light} \to \mathsf{RGB}\, \mathsf{Spectrum} \to \mathsf{Off} \to \mathsf{Flow} \to \mathsf{Ripple} \to \mathsf{Pulse} \to \mathsf{Blink}$

2. Color Mode:

When light mode is in Full Light, Pulse and Blink:

Switch over 8 LED colors .

 $\mathsf{Red} \to \mathsf{Yellow} \to \mathsf{Green} \to \mathsf{Teal} \to \mathsf{Blue} \to \mathsf{White} \to \mathsf{Purple} \to \mathsf{Wave}$

When light mode is in Ripple:

Switch over 7 LED colors .

 $\mathsf{Red} \to \mathsf{Yellow} \to \mathsf{Green} \to \mathsf{Teal} \to \mathsf{Blue} \to \mathsf{White} \to \mathsf{Purple}$

When light mode is in RGB Spectrum:

Click to memorize and lock the color you want, click again to unlock the 256 colors auto rotation.

When light mode is in Wave and Flow:

LED color can not be adjusted.

3. Light Speed:

Switch over between 4 light modes.

 $Slow \rightarrow Normal \rightarrow Fast \rightarrow Extreme$



