




## Parts List




**A** x 1

Thermal Grease




**B** x 1

Pinhead



**C** x 2

Cotton Swabs




**D** x 2

Alcohol Pads

## Thermal Grease Application Method

**⚠️ WARNING: Avoid Aluminum Materials**




1 Install the pinhead of TG-60.



2 Squeeze certain amount of Liquid Metal Thermal Grease on the CPU. (Please wipe it out if overflowed)



3 Apply the thermal grease evenly by cotton swabs.



4 Complete.