

TOWER 600 PERIPHERAL SETUP GUIDE

Congratulations on your new PC! Accessing the I/O panel and connecting your peripherals to the Tower 600 case is easy! Follow along this guide to learn how:

STEP 1

Remove the top cover by pulling up at the cutout on the back of the case.



STEP 3

Loosen the 2 thumb screws to swing the top fan bracket latch open to access the I/O ports from the top.

FRONT



васк

Disconnect any fan cables as needed to fully remove the top fan bracket.

STEP 2


For more space to access the I/O cutouts, remove the back panel by pulling on the notch at the top of the back panel.



STEP 4

Feed your cables through the the cutouts on their corresponding sides.

FRONT



All other peripherals

Monitors and other displays




NEED ADDITONAL HELP? CONTACT US:



TOWER 600 PERIPHERAL SETUP GUIDE

STEP 5 Connect your peripherals into the corresponding port(s) in the motherboard I/O.



^{**} Images for reference only. Port layouts may vary based on the included components.

For monitors and displays, connect directly to the appropriate port(s) on the graphics card/GPU.

Do NOT plug your monitor into the graphics port(s) on your motherboard, as it is disabled when a graphics card is installed in your system.

EXAMPLE OF FINAL CABLE WIRING ROUTE





