




F100 FORMULA

STEERING WHEEL

Assembly & User Manual

組裝&使用手冊

組裝&使用說明




F100 Formula Steering Wheel Assembly & User Manual

■ Product Introduction

The F100 Formula Steering Wheel is specially designed for the PC platform. It features a quick-release design, ergonomic construction, and provides a realistic racing experience, enhancing the fun and control of gameplay.

■ Product Features

- PC Platform Support : Compatible with Windows 7/10/11.
- Multifunctional Buttons : 12 function buttons + 2 thumb rotary knobs + 5-way joystick.
- Interchangeable Steering Wheel Rims : Quick-release design supports multiple rim options.
- Hall Effect Sensor Paddle Shifters : High sensitivity and long lifespan.




■ Package Contents


Item	Component Specification	Pcs
1	F100 Formula Steering Wheel	1
2	Silencers (for Paddle Shifters)	4
3	M2*51*17mm Hex Wrench (for Paddle Shifters)	1

■ Quick Release Instructions


1. Align the 6 steel balls on the steering wheel with the 6 grooves on the wheelbase.



2. Press the wheel into the wheelbase, keeping the guide line with each other.
3. The quick release will automatically snap into place, locking the wheel to the base. If the quick release does not lock, try rotating the panel on the base to its default position, and try again until it locks correctly.




4. To remove the wheel from the base, simply use two hands to pull back on the outer ring (black color) and pull the wheel out at the same time.



5. Navigate to Thermaltake (www.thermaltake.com) and download the latest version of the Thermaltake Racing Control Software. Install it and start your racing journey!


■ Installation of Paddle Silencer Pad

Push the paddle shifter to the opposite side, then attach the silencer pad to the base of the paddle (as shown in the picture).



■ Troubleshooting


1. If the steering wheel lights do not turn on after attaching it to the base, please remove and reattach it. Also, check if the base is properly connected to the power cord and turned on. Additionally, ensure both ends of the USB cable connected to the PC are securely plugged in.




2. If the steering wheel is unresponsive and the PC screen freezes, the system may have crashed. Please restart your computer.
3. If the steering wheel malfunctions during gameplay, exit the game first, re-plug the USB cable of the steering wheel, and enter the game again.
4. If the joystick or paddle shifters on the steering wheel are not functioning properly or behaving abnormally, please enter calibration mode to setting them.

Calibration Steps :


- a. Press and hold the A + VIEW buttons for 3 seconds to enter calibration mode (the wheel lights will start flashing alternately left and right).



- b. Move the joystick in all directions (up, down, left, right) and press each paddle shifter twice.



- c. Finally, press and hold the B + VIEW buttons for 1 second to complete the calibration.




■ Warnings

Safety Warnings:

- Use appropriate force when connecting, installing, or removing the product; do not twist or pull cables.
- Do not spill any liquid on the product or its ports.
- Keep the product in a dry place; do not expose it to fire, humidity, high temperatures, or oil fumes.
- Do not use the product if cables or ports are damaged, cracked, or broken.
- Do not attempt to disassemble, modify, or repair the product yourself. Repairs must be performed by the manufacturer, authorized representatives, or qualified technicians.
- Use only manufacturer-specified accessories and attachments.
- If the product emits unusual sounds, heat, or odors, stop use immediately, unplug the power cable, and disconnect other connections.

Force Feedback and Repetitive Motion Warning:


- Avoid prolonged gaming sessions.
- Take a 10 to 15-minute break after every hour of use.
- If you experience fatigue, pain, or discomfort in your hands, wrists, arms, legs, or feet, stop playing and rest for several hours before resuming.
- If symptoms persist after resuming, stop playing and consult a doctor.
- Keep the product out of reach of children.
- Ensure the racing wheel base and steering wheel are properly secured as instructed.
- Maintain a correct hand position on the wheel during gameplay.



Always keep



Absolutely
forbidden




Absolutely
forbidden

- Do not place hands or fingers under or near the pedals during use.
- Do not put hands or arms through the steering wheel openings during calibration or gameplay.
- This product is intended for users aged 16 and older.

F100 方程式賽車方向盤說明書 – 繁中版

■ 產品簡介

F100 方程式賽車方向盤，專為 PC 平台設計，支援快拆設計，符合人體工學，提供真實的賽車駕駛體驗，增加了遊戲操作的趣味性。



■ 產品特色


- 支援 PC 平台：適用 Windows 7 / 10 / 11。
- 多功能按鍵：12顆功能按鍵 + 2顆拇指旋鈕 + 1個五向搖桿。
- 快拆設計：更換其它盤面時可快速拆裝。
- 霍爾感應換檔撥片：靈敏度高，壽命長。

■ 內容物


項目	元件規格	數量
1	F100 方程式方向盤	1
2	消音片 (撥片消音用)	4
3	M2*51*17mm 內六角板手(調整撥片用)	1

■ 方向盤快拆安裝教程


1. 將方向盤快拆母頭上 6 顆 鋼珠的位置對應基座快拆公頭的 6 個凹槽。



2. 確認安裝指示線與之對齊，將盤面往基座方按壓。
3. 快拆將自動歸位鎖緊，若無鎖緊，可嘗試輕微轉動盤面或取下後再安裝。




4. 如需拆取盤面，用雙手捏住黑色快拆部分向後壓，同時並拔出盤面。



5. 於 Thermaltake 官網 (www.thermaltake.com) 下載最新版本的 Thermaltake Racing Control 軟體並安裝，即可開啟您的賽車之旅。

■ 安裝撥片靜音墊

將方向盤撥片往另一側推開，在把消音墊貼在撥片底座的位置 (如圖所示)。



■ 疑難排除


1. 當方向盤插到基座上，盤面燈不亮時請取下重新安裝一次，並檢查基座電源是否連接良好與開機起動，或檢查連接到PC上兩端 USB 線是否有插緊。




2. 當方向盤沒反應，電腦畫面不動，可能意外死機，請重新啟動電腦。
3. 當方向盤在遊戲中操作失靈時，請先退出遊戲並重新插拔方向盤 USB 線後再次進入遊戲。
4. 當方向盤上的搖桿與換檔撥片無功能或異常時，請進入校準模式做設定。

校準方式：


- a. 同時長按 A + VIEW鍵 3秒，進入模式 (盤面燈轉變為左右交替閃爍)。



- b. 上下左右移動搖桿與分別按下換檔撥片各兩次。



- c. 最後同時長按 B + VIEW鍵 1秒後完成校準。




■ 警語

安全警告：

- 連接、安裝和移除本產品時，請注意適當地用力，請勿扭曲或拉扯介面和線。
- 請勿將任何液體濺到產品或其介面上。
- 請將本產品置於乾燥處，請勿將其投入火中以及暴露於潮濕、高溫、油煙等環境下。
- 若電纜或其介面損壞、開裂或破損，請勿使用
- 請勿自行分拆、改裝及修理。任何維修必須由製造商、其授權代表或合格技術人員進行。
- 只能使用製造商指定的附著系統或配件。
- 如果本產品出現任何異常聲音、發熱或氣味，請立即停止使用，將電源線從電源插座上拔掉並斷開其他電纜。

力回饋和重複動作可能造成傷害，為避免發生意外，請參考使用建議：


- 避免遊戲時間過長。
- 使用本產品每一小時後應休息10到15分鐘。
- 如果感覺手、腕、手臂、腿或腳出現任何疲勞或疼痛，請停止遊戲並休息幾個小時，然後再重新開始遊戲。
- 重新開始遊戲之後，如果症狀或疼痛持續存在，請停止遊戲並諮詢醫生。
- 請放在兒童接觸不到的地方。
- 確保賽車方向盤基座和麵盤按照本手冊的說明完成固定。
- 雙手手勢：在遊戲過程中，要隨時保持雙手在方向盤處於正確位置，而不是隨意放置。



始終保持



絕對禁止



絕對禁止

- 在遊戲過程中，切勿將手或手指放在踏板下方或靠近踏板的任何位置。
- 在校準和遊戲過程中，切勿將手或手臂穿過方向盤的開口。

*本產品只能由年滿16歲或以上的使用者操作。



www.thermaltake.com