

XRW Quick Release Adapter


Assembly & User Manual
組裝&使用手冊
組裝&使用說明

XRW Quick Release Adapter Assembly & User Manual

快拆轉接器安裝說明書


■ Product Specifications (產品規格)

- Bolt circle: 70mm. (圓直徑: 70mm)
- Screw specification: M5, thread depth: 14mm. (螺絲規格: M5, 螺紋深度: 14mm)




■ Installation Steps (安裝步驟)

1. Mount the XRW Quick Release Adapter to your steering wheel.
(將 XRW 快拆轉接器安裝到方向盤上。)




2. Connect the USB cable included in the steering wheel package and plug the USB into your PC.
(連接方向盤包裝內附的 USB 線材並將 USB 連接到 PC 上。)



Notes : The cable length is subject to the actual product.
(備註：線材長度依實際為準。)

3. Insert the wheel (equipped with XRW Quick Release Adapter) into the base to complete the installation.
(將方向盤(配備 XRW 快拆轉接器)插入底座，即可完成連接。)



Notes : Illustrations are based on the Thermaltake XRW-G1 GT Steering Wheel.
(備註：圖示基於 Thermaltake XRW-G1 GT 方向盤。)



www.thermaltake.com