## Parts List

Ⓐ x 1 Ⓑ x 1 Ⓒ x 1

Intel Installation Guide

❶
ⓐ LGA1200/115X
ⓑ LGA1851/1700

LGA1851/1700
LGA1200/115X

Ⓑ

❷ Ⓒ

❸ Ⓐ Ⓑ

Fan & MB SYNC Installation Guide

⚠ **CAUTION** — Please power off the PC and check the Positive and Negative ends on the connector before connecting the cable to mainboard. Connecting the wrong end can damage the fans.

❶ Ⓐ
5V_ARGB
Z
Y
X
CPU_FAN

❷ X
MB

❸ Z
+5V D
ADD_HEADER