## Parts List

A x 1

B x 2

Intel
C x 4

Blue
D x 4

Black
E x 4

AMD
F x 4

G x 1

H x 1

I x 1

J x 2

Intel Installation Guide

1
ⓐ LGA1200/115X
ⓑ LGA1851/1700

LGA1851/1700
LGA1200/115X

A

ⓐ LGA1200/115X
ⓑ LGA1851/1700

LGA1851/1700
LGA1200/115X

B

2
LGA1851/1700
C
B
D
D Blue
A

LGA1200/115X
C
B
E
E Black
A

3
G

4
H

5
J
I

6
J

AMD Installation Guide

❶

❷

© AMD

B

© C

AM4/AM5

❸

F

B

E

E

Black

❹

G

❺

H

❻

J

I

❼

Fan & MB SYNC Installation Guide

⚠ **CAUTION** Please power off the PC and check the Positive and Negative ends on the connector before connecting the cable to mainboard. Connecting the wrong end can damage the fans.

❶

I

5V_ARGB

Y

Z

CPU_FAN

❷

Y

Z

MB